



PREMIUM AFTERMARKET WIND DEFLECTORS

Toyota MR2 Roadster Bars Wind Deflector



Attach the additional wind deflector using the supplied bolts. Install the plastic cap to cover the bolt.



Finished! Now enjoy your wind deflector